



WARNING: Before attempting to install or maintain this product, assure that your weapon is unloaded and the weapon safety is in the "safe" position

ASSEMBLING MAGNIFIER TO MOUNT

Note: The RRDM is designed to allow both left-hand flip (recommended for most applications) and right-hand flip. All images show the left-hand configuration.

- 1) Loosen the 6 Mount Screws using the included wrench, until the magnifier can fit in the ring.
- 2) Insert the magnifier into the mounting ring as shown in the picture.
 - a. Elevation Adjustment should point straight "up"
 - b. Optional: for right-hand flip, insert the magnifier in the opposite direction
- 3) Tighten the 6 Mount Screws until snug, then an additional $\frac{1}{4}$ turn. Do not over-tighten.

MOUNTING THE SIGHT

- 1) Position the magnifier behind your red dot optic.
 - a. Mount as close as possible, while still leaving room for operating your sight – about $\frac{1}{4}$ "
- 2) Tighten the mounting nut.

OPERATION

To flip – Pull back on the magnifier to release it from the locked position, then rotate the magnifier to the side.

- **To focus** - If the red dot is blurry, use the Diopter Adjustment and adjust until dot appears clear.

CENTERING THE DOT

After zeroing your optic, use the Windage and Elevation Adjustment Screws to center the red dot within your magnifier's sight picture. *Note – this step is optional, as it will not change the point of impact. It only centers the reticle in your magnifier.*

WARRANTY

AT3 Tactical products carry a lifetime warranty. Full details are available at at3tactical.com/warranty

If you have any issues or need a replacement, please contact us via email: support@at3tactical.com

